

Travis AFB Compatibility Zones

- Zone A
- Zone B1
- Zone B2
- Zone C
- Zone D
- Zone E
- Airport Influence Area
- LAMZ Overlay
- Runways
- Assault Landing Strip
- Travis AFB Property
- Travis AFB Easement

Rio Vista Airport Compatibility Zones


- Primary Surface
- Zone 1 - Runway Protection Zone
- Zone 2 - Inner Approach / Departure Zone
- Zone 3 - Inner Turning Zone
- Zone 4 - Outer Approach / Departure Surface
- Zone 5 - Sideline Zone
- Zone 6 - Traffic Pattern Zone

Nut Tree Airport Compatibility Zones

- Zone A
- Zone B
- Zone C
- Zone D
- Zone E
- Zone F

 City Boundary
 County Boundary

This is the official city boundary as approved by LAFCO.



Airport Compatibility Zones & Travis AFB Influence Area

